





**Board Stacker Terminals**

|                   |  |                   |
|-------------------|--|-------------------|
| <p><b>079</b></p> | <p><b>623</b></p>  | <p><b>062</b></p> |
| <p><b>060</b></p> | <p><b>063</b></p>  | <p><b>080</b></p> |
| <p><b>084</b></p> | <p><b>085</b></p>  | <p><b>088</b></p> |
| <p><b>065</b></p> | <p><b>Many other terminals and custom specific terminal styles are available on request, or refer to the pages 46 to 48 of this catalogue.</b></p> |                   |




**Application Examples**



Possible Terminals:

060; 062; 063; 065; 079  
080; 084; 085; 088; 623



Possible Terminals:

060; 062; 063; 079; 623

**Specifications**

See page 49 of this catalogue

How to order

**XXX - x xx - S xxx - xx**

|  |  |   |   |   |
|--|--|---|---|---|
| <p><b>Series</b><br/>POS<br/>POO<br/>PCL<br/>see page 14</p> | <p><b>DIP spacing</b><br/>in inch<br/>refer to table, dimension "B"<br/>on page 14</p> | <p><b>Nbr of contacts</b><br/>refer to table on page 14</p> | <p><b>Terminal style</b><br/>see drawings above<br/>or refer to pages 46 to 48 of this catalogue for other types.</p> | <p><b>Plating</b><br/>- 95 = tin/gold<br/>(tin leadfree)<br/>other on request</p> |
|--|--|---|---|---|

insert the corresponding data of the POS, POO or PCL column